

# LPC4 ECU

-

# REFERENCE MANUAL

Baldur Gíslason

September 20, 2022

## Contents

|       |                                    |    |
|-------|------------------------------------|----|
| 1     | Introduction                       | 3  |
| 2     | Wiring                             | 4  |
| 2.1   | Pin-outs and description . . . . . | 4  |
| 2.1.1 | Pin numbering . . . . .            | 4  |
| 2.1.2 | Connector A pin-out . . . . .      | 6  |
| 2.1.3 | Connector B pin-out . . . . .      | 7  |
| 2.1.4 | Connector C pin-out . . . . .      | 8  |
| 2.1.5 | Expansion board . . . . .          | 9  |
| 2.2   | Wiring diagram . . . . .           | 12 |
| 2.3   | Wiring guidelines . . . . .        | 13 |
| 2.3.1 | Grounding . . . . .                | 13 |

---

|       |   |    |
|-------|---|----|
| 2.3.2 | Engine speed sensors . . . . .            | 13 |
| 2.3.3 | Ignition outputs . . . . .                | 13 |
| 2.3.4 | Idle control . . . . .                    | 13 |
| 2.3.5 | Programmable outputs . . . . .            | 14 |
| 3     | Software configuration . . . . .          | 15 |
| 3.1   | Crank/cam trigger configuration . . . . . | 15 |
| 3.1.1 | Basic trigger . . . . .                   | 16 |
| 3.1.2 | Versatile multi tooth decoder . . . . .   | 17 |
| 3.1.3 | Dual edge trigger . . . . .               | 20 |
| 3.1.4 | Duty cycle coded trigger . . . . .        | 20 |
| 3.2   | Internal data logging . . . . .           | 20 |
| 3.3   | Performing firmware upgrades . . . . .    | 21 |
| 3.4   | OBD2 communications . . . . .             | 23 |
| 3.4.1 | Wiring . . . . .                          | 23 |
| 3.4.2 | Custom OBD2 PIDs . . . . .                | 24 |
| 3.4.3 | Transmitting data back . . . . .          | 25 |
| A     | Real time data fields . . . . .           | 27 |
| B     | Error codes . . . . .                     | 28 |
| C     | Old LPCX expansion board . . . . .        | 32 |
| C.1   | Wiring . . . . .                          | 32 |
| C.1.1 | Connector C pin-out . . . . .             | 34 |
| C.1.2 | Connector D pin-out . . . . .             | 35 |

# 1 Introduction

LPC4 is an engine management system for spark ignition engines, capable of sequential fuel injection on up to 6 cylinders and sequential ignition on up to 4 cylinder engines, bank fire and waste spark or distributor spark on engines with up to 8 cylinders. In addition to the more common four stroke engines, two strokes and Wankel type engines are supported as well.

LPC8 is an evolution of the LPC4 that adds sequential fuelling and ignition for up to 8 cylinders as well as more sensor inputs, including but not limited to an integrated wide band lambda sensor controller for Bosch LSU sensors and inputs for two knock sensors. On the LPC8, internal data logging and real time clock is standard fitment, but an option on the LPC4. The LPC8 also has electronic throttle control support standard while the LPC4 requires an add-on board for that.

It must be noted that many aspects of the configuration and strategies are also documented inside the configuration file. If you push F1 while editing a variable in the Calibrator application, you will get context sensitive help related to the category you are editing.

## 2 Wiring

### 2.1 Pin-outs and description

#### 2.1.1 Pin numbering




Figure 2.1: Connectors on the controller and their pin numbering. A and B are located on the back, C is only present on units with serial number 100 and up and is located on the front face.



## 2.1.2 Connector A pin-out

| Pin | I/O | Function                                 | Note   |
|-----|-----|--|--|
| 1   | OUT | 5V sensor supply                         | 200mA max  |
| 2   | IN  | Analog 0 - TPS<br>(APP A in ETC mode)    | 100k $\Omega$ pull-down                                  |
| 3   | IN  | Analog 1 - Lambda<br>(APP B in ETC mode) | 51k $\Omega$ pull-up                                     |
| 4   | OUT | Ground return for analog sensors         |  |
| 5   | IN  | Analog 4 0-5V                            | 51k $\Omega$ pull-up                                     |
| 6   | IN  | Analog 5 0-5V                            | 51k $\Omega$ pull-up                                     |
| 7   | IO  | CAN H                                    | 120 $\Omega$ termination                                 |
| 8   | IO  | CAN L                                    | 120 $\Omega$ termination                                 |
| 9   | OUT | Output 1 (Tach out)                      | Low-side switch, 5A max, 1k $\Omega$ pull-up to 12V      |
| 10  | OUT | Output 2 (Fuel pump relay)               | Low-side switch, 5A max                                  |
| 11  | IN  | Power ground                             |  |
| 12  | IN  | Power ground                             |  |
| 13  | IN  | Digital input 1                          | Active low, 5.7k $\Omega$ 5V pull-up, 12V safe           |
| 14  | IN  | Analog 2 - Coolant temperature sensor    | 3k $\Omega$ pull-up                                      |
| 15  | IN  | Analog 3 - Charge air temperature sensor | 3k $\Omega$ pull-up                                      |
| 16  | OUT | Ground return for crank/cam sensors      |  |
| 17  | IN  | Cam sync input                           | 2.2k $\Omega$ pull-up                                    |
| 18  | IN  | Crank trigger input                      | 2.2k $\Omega$ pull-up                                    |
| 19  | IN  | Digital input 5                          | Active low, 5.7k $\Omega$ 5V pull-up, 12V safe           |
| 20  | OUT | Ground for signal shields                | (or extra power ground)                                  |
| 21  | OUT | Output 4                                 | Low-side switch, 5A max                                  |
| 22  | OUT | Output 3 (PWM idle)                      | Low-side switch, 5A max. Clamping diode to supply 6 pin. |
| 23  | IN  | Digital input 2                          | Active low, 5.7k $\Omega$ 5V pull-up, 12V safe           |
| 24  | IN  | Switched +12V supply                     | Internally fused   |

## 2.1.3 Connector B pin-out

| Pin | I/O | Function                       | Note   |
|-----|-----|--------------------------------|--|
| 1   | OUT | Output 5 (PWM idle anti-phase) | Low-side switch, 5A max                          |
| 2   | OUT | Output 6                       | Low-side switch, 5A max                          |
| 3   | OUT | Injector 1                     | Low-side switch, 5A max                          |
| 4   | OUT | Injector 2                     | Low-side switch, 5A max                          |
| 5   | OUT | Injector 3                     | Low-side switch, 5A max                          |
| 6   | OUT | Injector 4                     | Low-side switch, 5A max                          |
| 7   | OUT | Output 7                       | Low-side switch, 5A max                          |
| 8   | OUT | Output 8                       | Low-side switch, 5A max                          |
| 9   | OUT | Ignition 1                     | 5V logic or low-side switch 10A max <sup>1</sup> |
| 10  | OUT | Ignition 2                     | 5V logic or low-side switch 10A max <sup>1</sup> |
| 11  | OUT | Ignition 3                     | 5V logic or low-side switch 10A max <sup>1</sup> |
| 12  | OUT | Ignition 4                     | 5V logic or low-side switch 10A max <sup>1</sup> |

---

<sup>1</sup>Depending on build time options

## 2.1.4 Connector C pin-out

This connector is only present on units with serial number 100 and up.

| Pin | I/O | Function              | Note  |
|-----|-----|-----------------------|---|
| 1   | OUT | Output 9              | Low-side switch, 1A max                                     |
| 2   | OUT | Output 10             | Low-side switch, 1A max                                     |
| 3   | IN  | Ignition switch input | 12V in to activate main relay, does not power ECU by itself |
| 4   | OUT | Main relay control    | Low-side switch, 1A max                                     |
| 5   | OUT | Output 11             | Low-side switch, 1A max                                     |
| 6   | OUT | Output 12             | Low-side switch, 1A max                                     |
| 7   | IO  | CAN bus 2 H           | Without 120 $\Omega$ termination                            |
| 8   | IO  | CAN bus 2 L           | Without 120 $\Omega$ termination                            |



### 2.1.5 Expansion board

In late 2019 a new expansion board was introduced, part number LPCX2. The expansion board installs inside the case and adds a third connector on the back providing 8 additional analog inputs, 2 additional digital inputs and 4 additional switching outputs.

Note that in firmware versions 2.11 and earlier the expansion board outputs are numbered from 9 up through 12.




Figure 2.2: Connector D, note that it is installed upside down on the controller.

| Pin | I/O | Function              | Note  |
|-----|-----|-----------------------|---|
| 1   | IN  | Power ground          | Join to wires connecting main ECU ground. Not necessary if not using outputs 13-16. |
| 2   | OUT | Output 13             | Low-side switch, 5A max, no PWM capability.   |
| 3   | OUT | Output 14             | Low-side switch, 5A max, no PWM capability.   |
| 4   | IN  | Digital in 3          | Active low, 12V tolerant. 10k $\Omega$ pull-up to 5V.                               |
| 5   | IN  | Analog in 10          | 3k $\Omega$ pull-up   |
| 6   | IN  | Analog in 8           | 51k $\Omega$ pull-up  |
| 7   | IN  | Analog in 15          | 51k $\Omega$ pull-up  |
| 8   | IN  | Analog in 16          | 51k $\Omega$ pull-up  |
| 9   | OUT | Sensor ground return  | Do not connect to any other ground  |
| 10  | IN  | Power ground          | Join to wires connecting main ECU ground. Not necessary if not using outputs 9-12.  |
| 11  | OUT | Output 11             | Low-side switch, 5A max, no PWM capability.   |
| 12  | OUT | Output 12             | Low-side switch, 5A max, no PWM capability.   |
| 13  | IN  | Digital in 4          | Active low, 12V tolerant. 10k $\Omega$ pull-up to 5V.                               |
| 14  | IN  | Analog in 11          | 51k $\Omega$ pull-up  |
| 15  | IN  | Analog in 9           | 51k $\Omega$ pull-up  |
| 16  | IN  | Analog in 13          | 51k $\Omega$ pull-up  |
| 17  | IN  | Analog in 15          | 51k $\Omega$ pull-up  |
| 18  | OUT | 5V supply for sensors | 200mA max (shared with other 5V outputs)  |




Figure 2.3: Solder jumpers on expansion board. Solder jumpers are the pads with no component mounted. SJ2 on top, SJ1 on bottom.

Digital inputs 2 and 3 can be configured for activation by a positive voltage instead of by grounding by the means of bridging solder jumpers on the expansion board. SJ1 pulls down input 3 and SJ2 pulls down input 2.

2.2 Wiring diagram




Figure 2.4: Typical basic wiring

## 2.3 Wiring guidelines

### 2.3.1 Grounding

The controller should be connected to the battery negative terminal or another reliable grounding point by a pair of  $1.5\text{mm}^2$  wires or a single  $6\text{mm}^2$  wire joined to smaller wires near the connector. An improper ground connection will cause electrical noise and possibly faults with controller operation. If utilising factory wiring, joining all of the supply ground wires for the original ECU should suffice.

### 2.3.2 Engine speed sensors

The inputs on the controller for crank/cam sensors are of schmitt trigger logic type, with  $2.2\text{k}\Omega$  pull-ups and with over-/undervoltage protection diodes. Thus they may be connected directly to open-collector or logic sensors (Hall effect, optical) or variable reluctance sensors. Some poorly designed VR sensors have an output voltage too small at cranking speeds for reliable starting, for those an amplifier module must be installed in the controller.

### 2.3.3 Ignition outputs

The default is to have four 5V logic-level outputs current limited to 18mA. Internal coil drivers for passive coils can be specified at order time, from 1 up to 4 coils.

### 2.3.4 Idle control

The LPC4 supports three types of idle control valves. 2 wire PWM, 3 wire PWM and 6 wire stepper. 4 wire stepper can be handled by fitting pull-up resistors to each wire. A value of  $15\Omega$  and 2W has been shown to work well on the common GM/Chrysler valves. A 2 wire PWM valve must be connected to output number 3. A 3 wire PWM valve uses outputs 3 and 5 to drive each coil. Stepper valves can be connected to any of the

outputs but usually outputs 5 through 8 are used, arrangement of the wiring does not matter as it can be configured in software.

### 2.3.5 Programmable outputs

The ECU has eight programmable outputs and while all low speed functions are applicable to every output, some PWM functions have dedicated outputs. This means that if those functions are used, they can only be assigned to the specified output. Outputs 1, 3 and 4 provide high accuracy PWM capability, with events timed to the nearest microsecond and a maximum PWM frequency of 2000Hz. Since firmware version 1.8, outputs 5 through 8 provide lower accuracy PWM capability with microsecond timing but possible timing error of individual pulses up to 100 microseconds. Maximum frequency on those outputs is 200Hz and although average error is on the order of zero, due to the nature of these software driven outputs occasional pulses may be out by as much as 100 microseconds. The exception is output 5 when in PWM idle anti phase mode, where it is driven at full 1 microsecond precision.

| Function            | Output |
|---------------------|--------|
| Tachometer output   | 1      |
| PWM idle control    | 3      |
| PWM idle anti-phase | 5      |

Figure 2.5: Functions with dedicated outputs

## 3 Software configuration

Refer to BG calibrator manual for introduction to the software. The default configuration file has the following defined keyboard shortcuts:

| Key | Function                      |
|-----|-------------------------------|
| F5  | Edit main fuel map            |
| F6  | Edit main ignition timing map |

### 3.1 Crank/cam trigger configuration

The LPC4 ECU has a unique way of dealing with crank/cam trigger signals. This enables it to decode a large variety of different trigger arrangements without needing the firmware to specifically support each arrangement. As a consequence the configuration of the trigger inputs may seem confusing to first time users. To combat this, presets are provided for common configurations, see the presets dialog in the calibrator software and check if your engine is listed.

In this chapter, the primary (or only) trigger is always referred to as the crank trigger, despite the possibility of the reluctor or shutter wheel being driven from the camshaft. The primary/cam filter periods let the ECU ignore any event occurring within a certain amount of time since the previous event. Useful against certain types of noise in certain trigger arrangements. Must be set to a lower number than the shortest anticipated event interval at maximum engine operating speed.

The modes of trigger input operation are as follows:

**Basic** Single impulse on crank trigger input for each cylinder's firing event. Works for configurations that only require a

single ignition output, either single cylinder, multi cylinder with distributor or multi cylinder running all cylinders in waste spark configuration. Also useful if no ignition control is required.

**Versatile multi tooth** The highly versatile crank/cam decoder for variable reluctance type crank sensors or hall effect setups where all the information required is available by decoding only one type of signal edge (rising or falling, not both).

**Dual edge** A variation of the versatile multi tooth decoder where alternating teeth defined are alternating polarity (rising or falling, starting with whichever is defined as the crank trigger active edge).

**Duty cycle coded** A variation of the versatile multi tooth decoder that triggers on one edge type (rising or falling) but measures the duty cycle, the ratio between high and low state. A pattern can then be entered denoting the duty cycle of past previous pulses and when that pattern is matched, the decoder generates a sync event. This arrangement is used on the earlier generation GM LS type engine (24X trigger) but this mode can also be configured to decode some Chrysler crank triggers.

**Log only** A mode that does not enable running an engine but does let one capture an event log of the crank/cam inputs without fuel being injected or ignited.

#### 3.1.1 Basic trigger

This mode has only three configurable options. The trigger angle offset whose useful range would be from zero up to the angle between firing events. (90 degrees on a 4 stroke V8 f.ex). The crank trigger active edge and the pulses skipped when starting options are also used. Cam sync, trigger teeth and other options not used. Primary trigger filter period does apply.



### 3.1.2 Versatile multi tooth decoder

The basic operating principle of the versatile multi tooth decoder is that each tooth sensed by the crank angle sensor is defined by the crank angle that separates it from the previous tooth before it. The crank angle of the first tooth in the cycle (aka trigger angle offset) in degrees before top dead centre cyl 1 is also defined, cyl 1 being assumed to have an angle offset of zero in the cylinder angle table. The trigger angle offset can have a value of anywhere from zero to 719 degrees. Used in conjunction with the tooth gap table is also a tooth repeat table. The tooth repeat table saves the user from having to configure multiple tooth entries where a number of adjacent teeth all have the same spacing. As an example a 36-1 crank trigger wheel only needs two tooth entries. 20 degrees and 10 degrees, and in that case the repeat values are 0 and 33 as the first tooth of the 35 that are present only occurs once, zero repetitions are performed. The second tooth and the 33 teeth that follow it have the same tooth spacing so a value of 33 is used for the second repeat value. From knowing the angle of the first tooth and the spacing of every tooth from the previous one, the decoder can calculate engine speed as well as crank angle every time an event occurs on the crank trigger input, but this information is not enough to let the decoder find its reference point in the cycle. To find the reference point and start decoding from tooth one, there are a number of strategies available. At the time of writing they are as follows:

**None** In this mode, cam sync is relied upon entirely for crank angle reference. In this mode, there must be enough teeth defined to cover the entire cycle so if there are 12 teeth on the crank, the tooth config must account for 24 teeth or sync is deemed lost before the next cam sync opportunity.

**Missing tooth** In this mode, the decoder compares the spacing of adjacent events and if the interval between events exceeds the interval of the previous event by a configurable threshold (typically at least 1.5), the current event is deemed to be tooth one and crank decoding can start. In this mode, the

first defined tooth must have its defined angle greater than the other teeth.

**Extra tooth** In this mode, the decoder compares the spacing of adjacent events and if the most recent interval is shorter than the previous interval by a configurable threshold (typically no more than 0.7, preferably less) then that tooth is ignored and the next event following it is deemed tooth one and decoding can start. There is a very good reason why the extra tooth is ignored in the code. For one, having extra crank angle resolution at one part of the cycle is of little benefit, but if the exact angle of the extra tooth is not known then it would be very detrimental to engine control to include it in the decoder output. Therefore, in this mode, the extra tooth must not exist in the tooth definitions, the first tooth is the tooth following the extra tooth.

If a cam position sensor is present, there are a number of different strategies available to decode that. The behaviour of the cam sync differs if a crank sync strategy is configured or not. When a crank sync strategy is configured, the cam sync will not apply unless crank sync has been found, and when that happens the crank angle will be set to the correct phase according to the angle offset of crank tooth #1. If no crank sync strategy is selected, then the cam sync will apply immediately.

The cam sync strategies are the following:

**Cam state on crank sync** This mode is useful for hall effect or similar logic output cam position sensors with a single wide tooth (half moon type). In this mode, the cam signal is not logged and no interrupts are generated on edge events but instead the state of the cam signal is polled when a crank sync event happens (missing tooth, extra tooth). If the cam input is in a logic low state (less than 1 volt input) then the configured angle offset is applied and full sync mode is entered. If the cam input is in a logic high state, then the configured angle offset is applied, shifted by 360 degrees and full sync mode is entered.

**Count cam impulses** This mode is useful for all types of sensors and applies to cam wheels with as little as a single tooth but also applies to more complex arrangements. In this mode, every event on the cam input increments a counter but every event on the crank input reads the counter and resets it to zero. If the counter value matches the configured cam sync count, then cam sync is applied at that crank event and full sync mode is entered.

An example where this mode is used is the Subaru 6/7 pattern, where a series of two or three cam impulses can be used to determine the crank angle and cam phase.

**Count crank impulses** This mode applies to certain crank/cam patterns where there are two or more cam teeth unevenly spaced or a greater number of evenly spaced cam teeth with some oddly spaced crank teeth. A counter is incremented on every crank event but read and reset on every cam event. If the counter matches the configured cam sync count then the following crank event will apply the cam sync. An example where this mode applies is Cosworth YB where the cam sync has two teeth spaced at 180 degrees of crank rotation.

**Primary trigger is cam** This mode allows the use of a missing tooth or extra tooth trigger wheel rotating at cam speed so the reference tooth angle is correct and no extra cam position information is required for full sync operation.

**Crank state on cam impulse** This mode only applies to dual-edge trigger decoder mode, used to decode DSM/Miata/Neon trigger. Has a configurable option for what the crank state must be for the cam event to register. The crank event following the cam event is deemed tooth number one.

**Cam count pattern** Principally the same as count cam impulses mode, except instead of comparing only the current value of the counter every crank event, a configurable number of previous values are also considered. This is useful if the

cam wheel has an insane amount of oddly spaced teeth, such as seen on early Chrysler/Jeep 4.7 V8.

### 3.1.3 Dual edge trigger

A mode for logic type sensors only (hall effect or optical). This mode is operationally identical to the versatile multi tooth trigger except that alternating teeth are expected to occur on alternating edges, with the first tooth occurring on the configured active edge for the crank trigger. Examples that use this include the Mitsubishi 4g63 and Mazda Miata, where it is used with cam sync.

### 3.1.4 Duty cycle coded trigger

A mode for logic type sensors only (hall effect or optical). This mode is operationally identical to the versatile multi tooth trigger except that the crank sync mode selector is not used. Instead it is hard coded to use a duty cycle pattern to sync. Normal trigger operation only happens on either a rising edge or a falling edge and the period since the last opposite edge divided by the period since the last active edge is the duty cycle. In the pattern, a value of 1 matches a duty cycle greater than 50% and a value of zero matches a duty cycle less than 50%. The pattern can have up to 8 positions. The typical use of this trigger mode is the GM LS1 engine, where it allows reliable operation with or without cam sync.

## 3.2 Internal data logging

As an option, the controllers can be fitted with internal data logging. The option involves fitting the hardware required for recording data inside the controller so the option must be fitted at purchase time or the unit returned to the vendor for reconfiguration. Controllers fitted with internal logging memory will generally have 8GB or more logging memory as well as a real time clock to time stamp the log files with time and date of when logging

started. Data recorded at the highest available logging rate (100Hz) will take up around 2 megabytes per minute. At the time of writing the download rate is around 3 megabytes per minute so a 30 minute data log recorded at the highest rate would take around 20 minutes to download from the controller. Data can only be downloaded when a log isn't being captured and the engine isn't running. For that reason it is recommended that the controller is configured to not start recording until engine speed reaches some non-zero number, except for testing of the logging function itself. Once logging is started, it will continue until the controller is powered off. It is important to note that the binary format of the log files changes when the firmware is updated, so old logs can be downloaded but will not convert correctly to csv format when the configuration file open in the Calibrator application does not match the firmware that recorded the log.

### 3.3 Performing firmware upgrades

Whenever new features are introduced, new firmware becomes available for download at <https://controls.is/firmware/>. See the release notes if you are unsure of whether you should update or not. To perform a firmware upgrade:

1. Download firmware package from web site
2. Unzip firmware package into a directory on your hard drive
3. Connect USB cable between ECU and PC.
4. Power on ECU, do not start engine.
5. If you do not have the configuration backed up, run BG Calibrator, read configuration from ECU and save to file. This step may be skipped if you are performing the upgrade on an ECU you haven't made any previous configuration changes to.
6. Run `upgrade.cmd` in directory where firmware files are located.

7. Wait until the upgrade application finishes, should be on the order of 10 seconds.
8. Power ECU off.
9. Do not power ECU back on until you are ready to upload configuration to it.

The ECU has been upgraded but now contains invalid configuration. If you are proceeding with default configuration, simply open the default configuration file for the new firmware in BG calibrator and go on-line, then send local settings when prompted about what to do with the ECU side configuration. Otherwise, if you wish to retain your previous configuration, which is generally recommended, perform the following steps:

1. Run the BG Calibrator software
2. Open your old configuration file
3. Select **File -> Convert configuration** from the menu bar.
4. Select the configuration included with the new firmware in the file dialog.
5. The configuration has now been converted to the new format, save it and exit the Calibrator software.
6. Run the Calibrator software again and open the configuration file you saved previously, choose to work off-line.
7. Review the settings and verify that they make sense, see release notes for information about what settings may need revisiting.
8. Go on-line and power on the ECU. Do not start engine.
9. When prompted, select to use local settings, which will then be uploaded to the ECU.

After the configuration has been sent to the ECU and Calibrator application becomes responsive again, power the ECU off and then back on. Now you can start the engine.

## 3.4 OBD2 communications

It is possible to perform OBD2 over CAN bus communications with the ECU. This enables the use of accessories that can display OBD2 data for instrumentation purposes (various OBD2 gauges, mobile phone applications and scan tools) as well as diagnostic trouble code readout. The protocol implemented is ISO15765-4 11 bit OBD over CAN.

To enable this functionality, the following configuration parameters must be set:

**CAN bus data mode** 500kbit

**CAN receiving enable** Enabled

**OBD2 service enable** Enabled

For diagnostic trouble codes, see Appendix B

### 3.4.1 Wiring




Figure 3.1: OBD2 female connector as seen from the end the scan tool plugs in to.

The OBD2 connector has four essential connections. Pin 6 (CAN-H) . Pin 14 (CAN-L) . Pins 4 and 5 connect to ground (any chassis ground will do) and pin 16 connects to +12V. The standard specifies that the +12V should be taken through a fuse directly from the battery but most OBD2 devices will also perform correctly if the 12V source is switched. For correct operation it may be necessary to have a 120 ohm termination resistor connected across the CAN wires if there is none connected to the CAN bus already.

### 3.4.2 Custom OBD2 PIDs

The ECU already implements nearly every standard OBD2 PID that is applicable to this application, but there are plenty of common sensors for which there is no documented standard OBD2 PID (for example, oil pressure) and also lots of examples of the ECU being used to monitor custom sensors. To facilitate this, custom OBD2 PIDs have been provided. The custom PIDs can be used to add PIDs and they can also override existing PIDs if desired. For a list of defined standard PIDs see [https://en.wikipedia.org/wiki/OBD-II\\_PIDs](https://en.wikipedia.org/wiki/OBD-II_PIDs)

It is safe to define custom PIDs in the range of 197 up to 223 (0xC5 to 0xDF in hex) without conflicting with any predefined PIDs.

In the Torque app, the OBD2 command to retrieve these values is 01 succeeded by the PID in hex, so to get PID 197 for example it would be 01 C5 OBD2 specifies the data is always in big-endian format meaning the most significant byte comes first, so the following data types are provided, but for most scenarios it is recommended to stick to either u8 or u16be:

- bit** Single bit to indicate a status, 1 or 0. Treat the same as a u8 byte but with only 2 possible values. Example formula in Torque app: **A**
- u8** Single unsigned byte ranging from 0 to 255. Example formula in Torque app: **A**
- s8** Single signed byte ranging from -128 to 127. Example formula in Torque app: **SIGNED(A)**
- u16be** 2 byte 16 bit unsigned integer ranging from 0 to 65535. Example formula in Torque app: **INT16(A:B)**
- s16be** 2 byte 16 bit signed integer ranging from -32768 to 32767. Not simple to use in Torque app, use unsigned value and offset it using input/output scaling on ECU instead.
- u32be** 4 byte 32 bit unsigned integer ranging from 0 to 4294967295. Example formula in Torque app: **INT32(A:B:C:D)**



**s32be** 4 byte 32 bit signed integer ranging from -2147483648 to 2147483647. Not simple to use in Torque app, use unsigned value and offset it using input/output scaling on ECU instead.

### 3.4.3 Transmitting data back

As of firmware version 2.3, the ECU provides a set of remotely manipulable bits that can be used to trigger things on or off, switching calibrations, etc. These bits can be manipulated by Calibrator scripts using the remote procedure call `remotebit` or using OBD2 commands. The results can be observed on the `remotebits` variables in the real time data.

To access the remote bits from OBD, use the **AA** command. The command takes 2 arguments. First argument is the bit number, from 00 to 07 and the second argument is the action to perform. The possible actions are:

**00** Flip bit to 0 state.

**01** Flip bit to 1 state.

**02** Toggle bit between states.

**03** Do nothing, just return current value.

**04** Flip bit to 1 momentarily and then back to 0 about half a second later.

The **AA** command sends a reply on channel **EA** with two data bytes, the first data byte being the bit number that was accessed and the second data byte being the new state of that bit. To read the status of a bit using a custom PID in Torque, send the command **AA 00 03** where 00 is the bit you wish to read. The formula for the return data is simply **B**. To alter a bit from Torque create a push button widget that sends a raw OBD command, for example **AA 00 02** to toggle bit 0 between states each time you push the button.

Manipulating these bits from a Calibrator script can be done in a similar manner. Example:

[ "rpc", "remotebit", [ 0, 2 ] ] to toggle bit 0.

# A Real time data fields

The descriptions of all the real time data fields have been moved into the configuration file as of firmware version 1.15. They can be read in the dialog for configuring the real time display or exported to a text document from Calibrator.

## B Error codes

The error codes are stored on four bit masks, error0, error1, error2 and error3. They can be read using the Calibrator application (Communication -> View controller errors in on-line mode, Tools -> Decode error variables in log view mode). It is also possible to read the errors using an OBD2 scan tool if OBD2 connector is wired and OBD2 communications are enabled in the configuration. OBD2 DTC codes take the form of P3XZZ where X is the error variable, 0 for error0 and so on and ZZ is the bit offset in that variable, starting with 00. Note that these codes do not correspond with any auto manufacturer's codes.

As of firmware 2.0 it is also possible to configure the check engine lamp to flash when error codes are present. The lamp will alternate between slow and fast flash rate, with the number of slow pulses preceding the number of fast pulses. For example, four slow flashes succeeded by a single fast flash signifies low battery voltage. In the following error code tables, the second column shows the number of flashes associated with each error code.

Errors that prohibit engine starting (error0):

| <b>Value</b> | <b>Count</b> | <b>Description</b>                                   |
|--------------|--------------|--|
| P3000        | 1-1          | Electronic throttle primary sensor low voltage       |
| P3001        | 1-2          | Electronic throttle primary sensor high voltage      |
| P3002        | 1-3          | Electronic throttle secondary sensor low voltage     |
| P3003        | 1-4          | Electronic throttle secondary sensor high voltage    |
| P3004        | 1-5          | Throttle position primary/secondary sensors disagree |
| P3005        | 1-6          | Electronic throttle not following target             |
| P3006        | 1-7          | Engine enable input not active                       |
| P3007        | 1-8          | Engine oil pressure low                              |
| P3008        | 1-9          | Slave processor software fault                       |
| P3009        | 1-10         | Slave processor hardware fault                       |
| P3010        | 1-11         | Test mode active                                     |
| P3011        | 1-12         | Hardware fault                                       |
| P3012        | 1-13         | Configuration error                                  |
| P3013        | 1-14         | Firmware crashed                                     |
| P3014        | 1-15         | Firmware crashed in interrupt mode                   |
| P3015        | 1-16         | Firmware crashed in priority interrupt               |

Errors that let the engine start and idle but disable the accelerator pedal in electronic throttle mode (error1):

| <b>Value</b> | <b>Count</b> | <b>Description</b>                              |
|--------------|--------------|---|
| P3100        | 2-1          | TPS voltage low                                 |
| P3101        | 2-2          | TPS voltage high                                |
| P3102        | 2-3          | Accelerator pedal primary sensor low voltage    |
| P3103        | 2-4          | Accelerator pedal primary sensor high voltage   |
| P3104        | 2-5          | Accelerator pedal secondary sensor low voltage  |
| P3105        | 2-6          | Accelerator pedal secondary sensor high voltage |
| P3106        | 2-7          | Accelerator pedal sensors disagree              |

Errors that will allow vehicle operation, but possibly at reduced performance (error2, error3 and error4):

| <b>Value</b> | <b>Count</b> | <b>Description</b>                         |
|--------------|--------------|--|
| P3200        | 3-1          | MAP sensor voltage low                     |
| P3201        | 3-2          | MAP sensor voltage high                    |
| P3202        | 3-3          | Coolant temp sensor open circuit           |
| P3203        | 3-4          | Coolant temp sensor short circuit          |
| P3204        | 3-5          | Air temp sensor open circuit               |
| P3205        | 3-6          | Air temp sensor short circuit              |
| P3206        | 3-7          | Lambda sensor voltage out of range         |
| P3207        | 3-8          | Lambda sensor lack of activity             |
| P3208        | 3-9          | Camshaft position sensor error             |
| P3209        | 3-10         | RTC battery fault or no RTC battery fitted |
| P3210        | 3-11         | Barometric pressure sensor low voltage     |
| P3211        | 3-12         | Barometric pressure sensor high voltage    |
| P3212        | 3-13         | EMAP sensor low voltage                    |
| P3213        | 3-14         | EMAP sensor high voltage                   |
| P3214        | 3-15         | MAP signal implausible                     |
| P3215        | 3-16         | Engine coolant temperature too high        |
| P3216        | 4-1          | Supply voltage too low                     |
| P3217        | 4-2          | Supply voltage too high                    |
| P3218        | 4-3          | Charge air temperature too high            |
| P3219        | 4-4          | Overboost protection triggered             |
| P3220        | 4-5          | Fuel pressure sensor low value             |
| P3221        | 4-6          | Fuel pressure sensor high value            |
| P3222        | 4-7          | Loss of CAN input data                     |
| P3223        | 4-8          | Fuel pressure low                          |
| P3224        | 4-9          | Fuel pressure high                         |
| P3225        | 4-10         | Engine coolant temperature implausible     |
| P3226        | 4-11         | VVT primary cam off target                 |
| P3227        | 4-12         | VVT secondary cam off target               |
| P3228        | 4-13         | Lambda reading too lean                    |
| P3229        | 4-14         | Lambda reading too rich                    |
| P3230        | 4-15         | MAF input low value                        |
| P3231        | 4-16         | MAF input high value                       |

| <b>Value</b> | <b>Count</b> | <b>Description</b>                         |
|--------------|--------------|--|
| P3300        | 5-1          | Lambda sensor 2 voltage out of range       |
| P3301        | 5-2          | Lambda sensor 2 lack of activity           |
| P3302        | 5-3          | Lambda 2 reading too lean                  |
| P3303        | 5-4          | Lambda 2 reading too rich                  |
| P3304        | 5-5          | N2O run aborted by low fuel pressure       |
| P3305        | 5-6          | Oil pressure sensor low value              |
| P3306        | 5-7          | Oil pressure sensor high value             |
| P3307        | 5-8          | Oil temperature sensor low value           |
| P3308        | 5-9          | Oil temperature sensor high value          |
| P3309        | 5-10         | VVT cam 3 off target                       |
| P3310        | 5-11         | VVT cam 4 off target                       |
| P3311        | 5-12         | Post compressor pressure sensor low value  |
| P3312        | 5-13         | Post compressor pressure sensor high value |
| P3313        | 5-14         | Post restrictor pressure sensor low value  |
| P3314        | 5-15         | Post restrictor pressure sensor high value |
| P3315        | 5-16         | Transmission temperature sensor low value  |
| P3316        | 6-1          | Transmission temperature sensor high value |
| P3317        | 6-2          | User defined error 1                       |
| P3318        | 6-3          | User defined error 2                       |
| P3319        | 6-4          | User defined error 3                       |
| P3320        | 6-5          | User defined error 4                       |
| P3321        | 6-6          | Injector duty cycle exceeded maximum       |
| P3322        | 6-7          | Knock sensor 1 low input signal            |
| P3323        | 6-8          | Knock sensor 2 low input signal            |
| P3324        | 6-9          | Excessive knock detected                   |
| P3325        | 6-10         | Fuel temperature sensor low input value    |
| P3326        | 6-11         | Fuel temperature sensor high input value   |
| P3327        | 6-12         | Fuel composition sensor low input value    |
| P3328        | 6-13         | Fuel composition sensor high input value   |
| P3329        | 6-14         | Mass air flow sensor signal implausible    |
| P3330        | 6-15         | DI fuel pressure sensor low input value    |
| P3331        | 6-16         | DI fuel pressure sensor high input value   |
| <b>Value</b> | <b>Count</b> | <b>Description</b>                         |
| P3400        | 7-1          | MAP sensor 2 low input value               |
| P3401        | 7-2          | MAP sensor 2 high input value              |
| P3402        | 7-3          | MAP sensor 2 implausible                   |

## C Old LPCX expansion board

An expansion board was available that fit inside the ECU case, part number LPCX. This expansion board adds 7 analog inputs, internal barometer, 2 extra digital inputs, 4 extra low side switch outputs and an H bridge drive output for electronic throttle control. If H bridge is used, only 3 of the low side drivers are available. The expansion board is incompatible with internal ignitors so if upgrading an ECU fitted with internal ignitors, external ignitors must be used instead.

This board has now been superseded by the LPCX2 which adds 8 analog inputs, 2 extra digital inputs and 4 extra low side switch outputs. New board does not include an H bridge but it is compatible with internal ignitors.

Note that in firmware versions 2.11 and prior the expansion board outputs are numbered from 9 up through 12.

### C.1 Wiring




Figure C.1: Connectors on the back of the expansion board.





## C.1.1 Connector C pin-out

| Pin | I/O | Function                         | Note   |
|-----|-----|----------------------------------|--|
| 1   | IN  | +12V supply for H bridge         | Not protected, use external 15A fuse. Only connect if using electronic throttle. |
| 2   | IN  | PWM input for H bridge           | Connect to pin 22 of connector A if using electronic throttle control.           |
| 3   | IN  | Analog 10<br>0-5V                | 3k $\Omega$ 5V pull-up   |
| 4   | IN  | Analog 8<br>0-5V                 | 100k $\Omega$ pull-down. Throttle position A when using ETC.                     |
| 5   | IN  | Analog 12<br>0-5V                | 51k $\Omega$ 5V pull-up  |
| 6   | IN  | Analog 14<br>0-5V                | 51k $\Omega$ 5V pull-up  |
| 7   | OUT | Ground return for analog sensors |  |
| 8   | OUT | 5V sensor supply                 | 200mA max, shared with other 5V outputs  |
| 9   | IN  | Digital input 3                  | Active low, 5.7k $\Omega$ 5V pull-up, 12V safe                                   |
| 10  | IN  | Digital input 4                  | Active low, 5.7k $\Omega$ 5V pull-up, 12V safe                                   |
| 11  | IN  | Analog 11<br>0-5V                | 3k $\Omega$ 5V pull-up   |
| 12  | IN  | Analog 9<br>0-5V                 | 51k $\Omega$ 5V pull-up. Throttle position B when using ETC.                     |
| 13  | IN  | Analog 13<br>0-5V                | 51k $\Omega$ 5V pull-up  |
| 14  | NC  | NC                               | Analog 15 if without internal barometric pressure sensor                         |
| 15  | OUT | Ground return for analog sensors |  |
| 16  | OUT | 5V sensor supply                 | 200mA max, shared with other 34 5V outputs                                       |

## C.1.2 Connector D pin-out

| Pin | I/O | Function          | Note  |
|-----|-----|-------------------|---|
| 1   | OUT | H bridge output 1 | Positive in forward (opening) direction. 15A max current      |
| 2   | OUT | H bridge output 2 | Positive in reverse (closing) direction. 15A max current      |
| 3   | IN  | Power ground      | Join to pins 11 and 12 on connector A                         |
| 4   | IN  | Power ground      | Join to pins 11 and 12 on connector A                         |
| 5   | OUT | Output 13         | Low-side switch, 5A max                                       |
| 6   | OUT | Output 14         | Low-side switch, 5A max                                       |
| 7   | OUT | Output 15         | Low-side switch, 5A max. Not available when H bridge is used. |
| 8   | OUT | Output 16         | Low-side switch, 5A max                                       |